



JDP-20FTD

20inch Drill Press

JT1-134..... 3~ 400V 50Hz

PARTS LIST



JPW Tool Group Hong Kong Limited

98 Granville Road, Tsimshatsui East, Kowloon, Hong Kong, PRC
www.jettools.com

Импортер в РФ: ООО «ИТА Технолоджи»


105082, Москва, Переведеновский пер., д. 17
www.jettools.ru

Made in PRC / Сделано в КНР

P-JT1-134

2023-05

Exploded View for JDP-20FTD Floor Drill Press



Parts List for JDP-20FTD Floor Drill Press

Index No	Part No	Description	Size	Qty
1	JDP20FTD-001	Base		1
2	TS-1505041	Socket Head Cap Screw	M10x30	4
201	JDP20FTD-201	Column Assembly (#3 thru 5)		1
3	JDP20FTD-003	Column Support		1
4	TS-1525011	Socket Set Screw	M10x10	2
5	JDP20FTD-005	Column		1
6	JDP20FTD-006	Rack		1
7	JDP20FTD-007	Table Support		1
202	JDP20FTD-202	Crank Arm Handle Assembly (#8 and 16)		1
8	JDP20FTD-008	Crank Arm Handle Grip		1
9	JDP20FTD-009	Crank Arm Sleeve		1
10	TS-1550021	Flat Washer	4	6
11	TS-2284082	Pan Head Machine Screw	M4x8	1
12	JDP20FTD-012	Knob		1
13	TS-1524021	Socket Set Screw	M8x10	1
14	JDP20FTD-014	Crank Arm Shaft		1
15	TS-2361041	Lock Washer	4	4
16	JDP20FTD-016	Retaining Ring	R14	1
203	JDP20FTD-203	Handle Assembly (#17 thru 18)		3
17	JDP20FTD-017	Handle		3
18	JDP20FTD-018	Knob		3
19	JDP20FTD-019	Gear Pin		1
20	JDP20FTD-020	Gear		1
21	JDP20FTD-021	Worm Gear		1
22	JDP20FTD-022	Wing Screw M8		1
23	JDP20FTD-023	Spring Pin	6x20	1
24	JDP20FTD-024	Hub		1
25	JDP20FTD-025	Depth Ring		1
26	JDP20FTD-026	Rivet	2.5x6	6
27	JDP20FTD-027	Spindle Scale		1
28	JDP20FTD-028	Pinion Shaft		1
29	TS-1523031	Socket Set Screw	M6x10	1
30	JDP20FTD-030	Rack Collar		1
31	JDP20FTD-031	Headstock		1
32	JDP20FTD-032	Spring Pin	6x20	1
33	JDP20FTD-033	Motor Base		1
34	TS-2361041	Lock Washer	4	2
35	JDP20FTD-035	Terminal Block		2
36	JDP20FTD-036	PE Terminal Block		2
37	TS-1504031	Socket Head Cap Screw	M8x16	4
38	JDP20FTD-038	Flat Washer	Φ17XΦ8.5X3	7
41	TS-1532032	Pan Head Machine Screw	M4x10	4
42	JDP20FTD-042	O-Ring 12		1
43	JDP20FTD-043ET	Motor Assembly	400V,50Hz,3PH	1
	JDP20FTD-043EM	Motor Assembly	230V,50Hz,1PH	1
	JDP20FTD-0431E	Starting Capacitor (not shown)		1
	JDP20FTD-0435E	Motor Fan (not shown)		1
	JDP20FTD-0436E	Motor Cover (not shown)		1
44	TS-2279351	Socket Set Screw	M10x35	1
45	TS-1541031	Lock Nut	M8	4
46	JDP20FTD-046	Plate		1
47	TS-2361081	Lock Washer	8	1
48	TS-1534032	Pan Head Machine Screw	M6x10	2
49	JDP20FTD-049	Motor Label		1
50	JDP20FTD-050	JET LOGO	JET-92	1
51	JDP20FTD-051	Shaft		1
52	JDP20FTD-052	Nut for Shaft		1
53	JDP20FTD-053	Pulley Cover		1
54	TS-1550041	Flat Washer	6	2
55	TS-1503011	Socket Head Cap Screw	M6x8	2


Index No	Part No	Description	Size	Qty
56	JDP20FTD-056	Center Pulley Shaft		1
57	JDP20FTD-057	Center Pulley		1
58	JDP20FTD-058	Key	C6x40	1
59	JDP20FTD-059	Motor Pulley		1
60	TS-1523031	Socket Set Screw	M6x10	2
61	JDP20FTD-061	V-Belt	A-710	2
62	JDP20FTD-062	Spindle Speed Label		1
63	BB-6202VV	Bearing	6202 w/2 seals	2
64	JDP20FTD-064	Distance Sleeve		4
65	TS-1524031	Socket Set Screw	M8x12	2
66	JDP20FTD-066	Spindle Pulley		1
67	JDP20FTD-067	Key	C10X7.2X35	1
204	JDP20FTD-204	Drive Sleeve Assembly (# 67 thru 70)		1
68	JDP20FTD-068	Drive Sleeve		1
69	JDP20FTD-080	Spacer		1
70	BB-6007VV	Ball Bearing	6007 W/2 Seals	2
71	JDP20FTD-071	Laser Board Assembly		1
72	TS-2285502	Pan Flat Machine Screw	M5x40	2
73	JDP20FTD-073	LED Circuit Board		1
74	TS-1502021	Socket Head Cap Screw	M5x10	2
75	TS-1490011	Hex Cap Screw	M8x12	4
76	TS-1550061	Flat Washer	8	4
77	JDP20FTD-077	O-Ring 22		1
78	TS-1550031	Flat Washer	5	2
79	TS-1541011	Hex Nut	M5	2
80	TS-2361051	Lock Washer	5	2
81	JDP20FTD-081	Press Plate		2
82	TS-1550031	Flat Washer	5	2
83	TS-1533052	Pan Head Machine Screw	M5x16	3
84	JDP20FTD-084	Rubber Washer	9X18X2.5	6
85	TS-1525011	Socket Set Screw	M10x10	1
86	JDP20FTD-086	Bushing for cord	M16	1
87	TS-1541001	Hex Nut	M4	1
88	JDP20FTD-88	Plate		1
89	JDP20FTD-89	Pin		1
90	TS-1501091	Socket Head Cap Screw	M4x35	2
91	JDP20FTD-91	Limit Switch	QKS8	1
92	JDP20FTD-092	Terminal Block		2
93	JDP20FTD-093	LED Lamp		1
94	JDP20FTD-094	Terminal Block		2
95	JDP20FTD-095T	Power Cord with Plug	400V	1
	JDP20FTD-095M	Power Cord with Plug	230V	1
96	TS-1534042	Pan Head Machine Screw	M6x12	1
97	JDP20FTD-097	Flat Washer	Φ18XΦ6.5X2	1
98	JDP20FTD-098	Nut		1
205	JDP20FTD-205	Coil Spring Assembly (#99 and 101)		1
99	JDP20FTD-099	Spring Housing		1
100	JDP20FTD-100	Coil Spring		1
101	TS-2284082	Pan Head Machine Screw	M4x8	1
102	JDP20FTD-102	Self-Tapping Screw	ST2.9x9.5	8
103	TS-1550011	Flat Washer	3	4
104	JDP20FTD-104	Warning Label		1
105	JDP20FTD-105	Plate		1
106	TS-2311101	Hex Nut	M10	1
107	TS-1525051	Socket Set Screw	M10x25	1
108	JDP20FTD-108	PCB Board		1
109	JDP20FTD-109	PCB Board Press		1
110	JDP20FTD-110	Switch Box		1
111	JDP20FTD-111	Self-Tapping Screw	ST3.5x13	2
112	JDP20FTD-112	PCB Window		1
113	JDP20FTD-113	LED Switch		1
114	JDP20FTD-114	Wrench		1

Index No	Part No	Description	Size	Qty
115	TS-1550071	Flat Washer	10	4
116	JDP20FTD-116	Switch		1
118	JDP20FTD-118	Rubber Washer		1
119	BB-6005VV	Ball Bearing	6005 W/2 Seals	1
120	JDP20FTD-120	Retaining Ring	25	1
121	TS-1532042	Pan Head Machine Screw	M4x12	2
122	TS-2244162	Socket Head Cap Screw	M4x16	2
123	TS-1521011	Socket Set Screw	M4x4	2
124	TS-1521031	Socket Set Screw	M4x8	8
125	JDP20FTD-125	Gear Base		1
126	JDP20FTD-126	Gear		1
127	JDP20FTD-127	Shaft		1
129	TS-1501031	Socket Head Cap Screw	M4x10	2
130	JDP20FTD-130	Sensor Seat		1
132	JDP20FTD-132	Poiter		1
133	JDP20FTD-133	Pin with Screw	M6X5X28	1
134	JDP20FTD-134	Sensor A		1
136	JDP20FTD-136	Angle Scale		1
138	JDP20FTD-138	Scale Indicator Bracket		1
139	TS-2361201	Lock Washer	20	1
140	JDP20FTD-140	Hex Cap Screw	M20x55	1
141	JDP20FTD-141	Table		1
142	JDP20FTD-142	Lock Handle		1
143	JDP20FTD-143	Wedge Shifter		1
144	JDP20FTD-144	Quill		1
145	B-51107VV	Bearing	51107W/2 Seals	1
146	BB-6206VV	Ball Bearing	6206 W/2 Seals	1
147	JDP20FTD-147	Spindle		1
148	JDP20FTD-148	Arbor	MT3/B18	1
149	JDP20FTD-149	Keyless Chuck	B18	1
150	JDP20FTD-150	Handle		1
151	TS-2284082	Pan Head Machine Screw	M4x8	1
154	JDP20FTD-154	Sleeve		1
155	JDP20FTD-155	Shaft		1
156	JDP20FTD-156	Crank Arm Handle Grip		1
157	TS-1524021	Socket Set Screw	M8x10	1
158	JDP20FTD-158	Lead Screw		1
159	JDP20FTD-159	Large Washer	16	1
160	TS-1524041	Socket Set Screw	M8x16	1
161	JDP20FTD-161	Plate for Vise		1
162	TS-1515011	Socket Flat Screw	M8x12	2
163	JDP20FTD-163	Floating Jaw for Vise		1
164	TS-1490081	Hex Cap Screw	M8x45	1
165	JDP20FTD-165	Adjustment Screw		1
166	JDP20FTD-166	Press Plate		1
167	JDP20FTD-167	Stationary Jaw for Vise		1
168	TS-1523081	Socket Set Screw	M6x30	2
169	TS-1540041	Hex Nut	M6	1
170	TS-1523071	Socket Set Screw	M6x25	1
171	JDP20FTD-171	Gib		2
172	TS-1504061	Socket Head Cap Screw	M8x30	6
174	JDP20FTD-174	Adjustment Handle		1
175	JDP20FTD-175	Stop Plate		1
176	JDP20FTD-176	Vise Way Left		1
177	JDP20FTD-177	Vise Way Right		1
178	TS-1505031	Socket Head Cap Screw	M10x25	4
179	JDP20FTD-179	Lock Block Left		1
180	JDP20FTD-180	Lock Block Right		1
181	JDP20FTD-181	Chuck Guard Assembly		1
	JDP20FTD-ID	ID Label (not shown)		1

Wiring Diagram for JDP-20FTD Floor Drill Press

	colour of strands	Litzenfarben	couleur des cordons
BK	black	schwarz	noir
WH	white	weiß	blanc
BU	blue	blau	bleu
RD	red	rot	rouge
BN	brown	braun	brun
GY	grey	grau	gris
GNYE	green-yellow	grün-gelb	vert-jaune
	meaning of symbol	Bedeutung der Zeichen	interprétation
M	motor	Motor	moteur
S	switch	Schalter	interrupteur
C1	Condenser of running	Kondensator	condensateur
C2	Condenser of Starting	Kondensator	condensateur
n	centrifugal switch	Fliehkraftschalter	déclencheur centrifuge
OL	overload cut-off	Überlastschutzschalter	déclencheur surcharge
LS	limit switch	Positionsendschalter	micro
SB	E-stop	Not-Aus Taster	arret d'urgence

3 ~ 400V, 50Hz



~ 230V, 50Hz

