



MBS-2128DAS Semi-Auto bandsaw

MBS-2128DAS.....50000343T..... 3~400V, 50Hz

PARTS LIST



JPW Tool Group Hong Kong Limited

98 Granville Road, Tsimshatsui East, Kowloon, Hong Kong, PRC

www.jettools.com

Импортер в РФ: ООО «ИТА Технолоджи»

105082, Москва, Переведеновский пер., д. 17


www.jettools.ru

Made in Taiwan / Сделано на Тайване

P-50000343T

2022-09

MBS-2128DAS Stand Assembly



SECTION A

MBS-2128DAS Stand Assembly

Index No.	Part No.	Description	Size	Q'ty
1	TS-0209051E	Hex. Socket Cap Screw	3/8"x1" L	1
2	MBS2128DAS-A2	Spring Washer	3/8"	1
3	MBS2128DAS-A3	Washer		1
4	TS-0270021E	Set Screw	5/16"x5/16"L	1
5	MBS2128DAS-A5	Holding Bracket		1
6	TS-0209051E	Hex. Socket Cap Screw	3/8"x1"L	1
7	MBS2128DAS-A7	Spring Washer	3/8"	1
8	MBS2128DAS-A8	Washer		1
9	MBS2128DAS-A9	Spring Washer	3/8"	1
10	TS-0209051E	Hex. Socket Cap Screw	3/8"x1"L	1
11	MBS2128DAS-A11	Length Bar Bracket		1
12	MBS2128DAS-A12	Stopper		1
13	MBS2128DAS-A13	Welding Shaft		1
14	MBS2128DAS-A14	Length Bar		1
15	MBS2128DAS-A15	Adjusting Block		1
16	MBS2128DAS-A16	Locking Handle	3/8x30L	1
17	MBS2128DAS-A17	Washer		1
18	MBS2128DAS-A18	Spring Washer	3/8"	1
19	TS-0209051E	Hex. Socket Cap Screw	3/8"x1"L	1
20	MBS2128DAS-A20	Length Bar Bracket (R)		1
21	TS-0270021E	Set Screw	5/16"x5/16"L	1
22	MBS2128DAS-A22	Washer		1
23	MBS2128DAS-A23	Spring Washer	3/8"	1
24	TS-0209051E	Hex. Socket Cap Screw	3/8"x1"L	1
25	TS-1491031E	Hex. Cap Bolt	M10x25L	4
26	MBS2128DAS-A26	Spring Washer	M10	4
27	MBS2128DAS-A27	Flat Washer	M10	4
28	TS-0246031E	Flat Head Screw	5/16"x3/4"L	4
29	MBS2128DAS-A29G	Side Plate		1
30	MBS2128DAS-A30	Coolant Tray Bracket		2
31	MBS2128DAS-A31G	Machine Base		1
32	MBS2128DAS-A32G	Movable Cover		1
33	MBS2128DAS-A33	U Type Handle		1
34	MBS2128DAS-A34	Big Round Head Screw	M6x12L	2
35	MBS2128DAS-A35	Flat Washer	M12	4
36	MBS2128DAS-A36	Spring Washer	M12	4
37	TS-1492011E	Hex. Cap Bolt	M12x25L	4
38	MBS2128DAS-A38G	Retrieving Device		1
39	MBS2128DAS-A39G	Coolant Tray (R)		1
39-1	MBS2128DAS-A39-1	Button Head Socket Screw	M6x8L	4
39-2	MBS2128DAS-A39-2	Cover		1
39-3	MBS2128DAS-A39-3	Button Head Socket Screw	M4x8L	2
39-4	MBS2128DAS-A39-4	Blade Stuck Overload Relay		1
39-5	MBS2128DAS-A39-5	Button Head Socket Screw	M6x8L	4
39-6	MBS2128DAS-A39-6	Bracket		1
40	TS-2246082E	Round Head Socket Screw	M6x8L	4
41	MBS2128DAS-A41G	Inverter Cover		1
42	MBS2128DAS-A42G	Coolant Tray Bracket (R/L)		3
43-2	MBS2128DAS-A43-2	Inverter	CT 7.5Hp	1
44	MBS2128DAS-A44	Round Head Screw	M5x12L	4
45	MBS2128DAS-A45	Hydraulic Unit		1
46	TS-2246122E	Round Head Socket Screw	M6x12L	2
47	MBS2128DAS-A47G	Hydraulic Unit Cover		1
48	TS-2246082E	Round Head Socket Screw	M6x8L	4
49	MBS2128DAS-A49G	Coolant Tray Bracket (Rf)		1
50	TS-1494052E	Steel Hex. Cap Bolt	M16x60L	4
51	MBS2128DAS-A51	Nut	M16	4
52	MBS2128DAS-A52	Pressure Regulator		1
52-1	MBS2128DAS-A52-1G	Movable Coolant Tray		2
52-2	TS-1482021E	Hex. Cap Bolt	M6x12L	4


MBS-2128DAS Stand Assembly

Index No.	Part No.	Description	Size	Q'ty
52-3	MBS2128DAS-A52-3G	Tray Bracket		2
52-4	MBS2128DAS-A52-4	Nut	M6	4
52-5	MBS2128DAS-A52-5	Nut	1/2"	2
52-6	MBS2128DAS-A52-6	Adjusting Screw		2
53	MBS2128DAS-A53	Lock Pin	8x50L	2
54	TS-1503071E	Hex. Socket Cap Screw	M6x30L	1
55	MBS2128DAS-A55	Spring Washer	M6	1
56	MBS2128DAS-A56	Flat Washer	M6	1
57	MBS2128DAS-A57G	Cabinet Door		1
57-1	MBS2128DAS-A57-1	PC Board	PCB1	1
57-2	MBS2128DAS-A57-2	O.L. Indicator Light		1
58	TS-2246162E	Round Head Socket Screw	M6x16L	4
59	MBS2128DAS-A59	Control Base		1
60	TS-2246162E	Round Head Socket Screw	M6x16L	4
61	MBS2128DAS-A61	Spring Washer	M6	4
62	MBS2128DAS-A62G	Electrical Box		1
63	MBS2128DAS-A63	Flat Washer	M10	4
64	MBS2128DAS-A64	Spring Washer	M10	4
65	TS-1491041E	Hex. Cap Bolt	M10x30L	4
66	MBS2128DAS-A66	Spring Washer	M10	4
67	TS-1491041E	Hex. Cap Bolt	M10x30L	4
68-1	MBS2128DAS-A68-1	Moving Shaft		1
69	MBS2128DAS-A69G	Shaft Holder Base		2
70	MBS2128DAS-A70	Shaft Holder		2
71	MBS2128DAS-A71G	Back Cover		1
72	TS-2245122E	Round Head Screw	M5x12L	4
73	MBS2128DAS-A73	Nut	M8	10
74	MBS2128DAS-A74	Spring Washer	M8	10
75	MBS2128DAS-A75	Flat Washer	M8	10
76	MBS2128DAS-A76G	Coolant Tray (L)		1
77	TS-2208201E	Hex. Cap Bolt	M8x20L	10
78	TS-1517021E	Flat Head Screw	M12x30L	5
79	MBS2128DAS-A79	Swiveling Guide Plate		1
80	TS-1482031E	Hex. Cap Bolt	M6x16L	2
81	MBS2128DAS-A81	Spring Washer	M6	2
82	MBS1824DAS-A98	Coolant Pump	1/6Hpx150L	1
83	MBS2128DAS-A83	Coolant Pump Bracket		1
84	TS-2246082E	Round Head Socket Screw	M6x8L	2
85	MBS2128DAS-A85G	Pump Cover		1
86	TS-2246082E	Round Head Socket Screw	M6x8L	4
87	MBS2128DAS-A87G	Chip Collected		1
88-1	MBS2128DAS-A88-1G	Coolant Tray		1
89	MBS2128DAS-A89	Flat Washer	M8	2
90	MBS2128DAS-A90	Spring Washer	M8	2
91	TS-2228161E	Hex. Cap Bolt	M8x16L	2
92	TS-2246082E	Round Head Socket Screw	M6x8L	6
93	TS-2246082E	Round Head Socket Screw	M6x8L	4
94	MBS2128DAS-A94G	Cover		1
95	TS-2246082E	Round Head Socket Screw	M6x8L	4
96	MBS2128DAS-A96G	Control Box		1
97	MBS2128DAS-A97	U Type Handle		2
98	MBS2128DAS-A98	Control PCB		1
99	MBS2128DAS-A99	Round Head Socket Screw	M5x8L	4
100	MBS2128DAS-A100	Bow Height PCB		1
101	MBS2128DAS-A101	Round Head Socket Screw	M4x6L	2
102	MBS2128DAS-A102	Magnifier		1
103	MBS2128DAS-A103	Magnifier Holder		1
104	MBS2128DAS-A104	Height Scale Cover		1
105	MBS2128DAS-A105	Round Head Socket Screw	M4x6L	2
106	MBS2128DAS-A106	Nut	M6	2

MBS-2128DAS Stand Assembly

Index No.	Part No.	Description	Size	Q'ty
107	MBS2128DAS-A107	Cover Bracket		1
108	TS-2244122E	Round Head Socket Screw	M4x12L	2
109	MBS2128DAS-A109G	Bracket Cover		1
110	TS-2246082E	Round Head Screw	M6x8L	6
111	MBS2128DAS-A111G	Control Box Bracket		1
112	TS-2246082E	Round Head Socket Screw	M6x8L	4
113	MBS2128DAS-A113G	Swiveling Bracket		1
114	TS-1482031E	Hex. Cap Bolt	M6x16L	4
115	TS-1490021E	Hex. Cap Bolt	M8x16L	4
116	MBS2128DAS-A116	Spring Washer	M8	4
117	MBS2128DAS-A117G	Swiveling Base		1
118	MBS2128DAS-A118	Adjusting Handle	M8x30L	1
119	TS-1524051E	Set Screw	M8x20L	2
120	MBS2128DAS-A120	Nut	M8	2
121	MBS2128DAS-A121	Spring Washer	M8	4
122	TS-2228161E	Hex. Cap Bolt	M8x16L	4
123	MBS2128DAS-A123G	Connect Base		1

MBS-2128DAS Rotary Mechanism Assembly



MBS-2128DAS Rotary Mechanism Assembly

Index No.	Part No.	Description	Size	Q'ty
1.....	MBS2128DAS-B1.....	Round Head Socket Screw.....	M5x8L.....	4
2.....	MBS2128DAS-B2G.....	Dust Cover.....		1
3.....	MBS2128DAS-B3.....	Rubber Handle.....		1
4.....	MBS2128DAS-B4.....	Nut.....	M12.....	1
5.....	MBS2128DAS-B5.....	Locking Rod.....		1
6.....	MBS2128DAS-B6.....	Locking Bolt.....		1
7.....	MBS2128DAS-B7.....	Connecting Block.....		1
8.....	TS-1505081E.....	Hex. Socket Cap Screw.....	M10x50L.....	1
9.....	MBS2128DAS-B9.....	Brake Plate.....		1
10.....	TS-1504041E.....	Hex. Socket Cap Screw.....	M8x20L.....	2
11.....	MBS2128DAS-B11.....	Brake Bracket.....		1
12.....	TS-1505061E.....	Hex. Socket Cap Screw.....	M10x40L.....	1
13.....	MBS2128DAS-B13.....	Cam Spring.....		1
14.....	MBS2128DAS-B14.....	Nut.....	M10.....	1
15.....	MBS2128DAS-B15.....	Connecting Plate.....		1
16.....	MBS2128DAS-B16.....	C Ring.....	S16.....	1
17.....	TS-1504051E.....	Hex. Socket Cap Screw.....	M8x25L.....	1
18.....	MBS2128DAS-B18.....	Cam Bracket.....		1
19.....	MBS2128DAS-B19.....	Cam Shaft.....		1
20.....	BB-6000ZZE.....	Bearing.....	6000ZZ.....	1
21.....	MBS2128DAS-B21.....	Spring Washer.....	M10.....	1
22.....	MBS2128DAS-B22.....	Nut.....	M10.....	1
23.....	MBS2128DAS-B23.....	Spring Pin.....	8x20L.....	2
24.....	TS-1505021E.....	Hex. Socket Cap Screw.....	M10x20L.....	5
25.....	MBS2128DAS-B25.....	Spring Washer.....	M10.....	5
26.....	TS-1505021E.....	Hex. Socket Cap Screw.....	M10x20L.....	8
27.....	TS-1481041E.....	Steel Hex. Cap Bolt.....	M5x16L.....	1
28.....	MBS2128DAS-B28.....	Wire Fastener.....		1
29.....	MBS2128DAS-B29.....	Angle Position Plate.....		1
30.....	MBS2128DAS-B30.....	Lower Cover.....		1
31.....	MBS2128DAS-B31.....	O Ring.....	P60.....	2
32.....	MBS2128DAS-B32.....	Taper Bearing.....	30312.....	2
33-1.....	MBS2128DAS-B33-1G.....	Swiveling.....		1
34.....	MBS2128DAS-B34.....	Swiveling Shaft.....		1
35.....	MBS2128DAS-B35.....	Upper Cover.....		1
36.....	TS-1523071E.....	Set Screw.....	M6x25L.....	1
37.....	TS-1504041E.....	Hex. Socket Cap Screw.....	M8x20L.....	8
38.....	MBS2128DAS-B38.....	Tighten Plate.....		1
39.....	TS-1504041E.....	Hex. Socket Cap Screw.....	M8x20L.....	4
39-1.....	MBS2128DAS-B39-1.....	Spring Center Shaft.....		1
39-2.....	MBS2128DAS-B39-2.....	Counter Pressure Spring.....		1
39-3.....	MBS2128DAS-B39-3.....	Spring Adjustment Washer.....		1
39-4.....	MBS2128DAS-B39-4.....	Spring Adjustment Nut.....		1
39-5.....	MBS2128DAS-B39-5.....	Rod End.....	POS 20.....	1
40.....	MBS2128DAS-B40.....	Cylinder Lower Bracket.....		2
40-1.....	MBS2128DAS-B40-1.....	Cylinder Lower Shaft.....		2
40-2.....	MBS2128DAS-B40-2.....	C Ring.....	S20.....	4
41.....	TS-1491101E.....	Hex. Cap Bolt.....	M10x60L.....	1
42.....	MBS2128DAS-B42.....	Hex. Cap Bolt.....	M20x65L.....	1
43.....	MBS2128DAS-B43.....	Nut.....	M10.....	1
44.....	MBS2128DAS-B44.....	Nut.....	M20.....	1
45.....	MBS2128DAS-B45.....	Dust Cover.....		1
46.....	MBS2128DAS-B46.....	Fixing Plate.....		1
47.....	MBS2128DAS-B47.....	Spring Washer.....	M6.....	3
48.....	TS-2246202E.....	Round Head Socket Screw.....	M6x20L.....	3
49.....	MBS2128DAS-B49.....	Support Bracket.....		2
50.....	BB-6201ZZE.....	Bearing.....	6201.....	2
51.....	MBS2128DAS-B51.....	Bearing Shaft.....		2
52.....	TS-1521021E.....	Set Screw.....	M4x6L.....	2
53.....	TS-1504041E.....	Hex. Socket Cap Screw.....	M8x20L.....	4


MBS-2128DAS Rotary Mechanism Assembly

Index No.	Part No.	Description	Size	Q'ty
54	MBS2128DAS-B54	Spring Washer	M8	4
55	TS-1490071E	Steel Hex. Cap Bolt	M8x40L	4
56	MBS2128DAS-B56	Spring Washer	M8	4
57	MBS2128DAS-B57	Adjusting Screw	M16	4
58	MBS2128DAS-B58	Support Plate		1
59	MBS2128DAS-B59	Nut	1/2"	2
60	MBS2128DAS-B60	Spring Washer	1/2"	2
61	TS-1504051E	Hex. Socket Cap Screw	M8x25L	4
62	MBS2128DAS-B62	Spring Washer	M8	4
63	MBS2128DAS-B63	Set Plate		1
64	MBS2128DAS-B64	Screw Holder	1/2"x50L	2
65	MBS2128DAS-B65	Coolant Nozzle	1/4"x30"	1
66	MBS2128DAS-B66	Wing Screw	M6x20L	2
67	MBS2128DAS-B67	Nozzle Seat		1
68	MBS2128DAS-B68	Coolant Switch	1/4x1/4	1
69	TS-1506031E	Hex. Socket Cap Screw	M12x30L	12
70	MBS2128DAS-B70	Vise Jaw-Right		1
71	MBS2128DAS-B71	Vise Jaw-Left		1
72	TS-1504041E	Hex. Socket Cap Screw	M8x20L	2
73	MBS2128DAS-B73	Hex. Socket Cap Screw	M8x90L	2
74	MBS2128DAS-B74	Cutting Plate		1
75	TS-1505141E	Hex. Socket Cap Screw	M10x90L	2
75-1	MBS2128DAS-B75-1	Pin		2
76	MBS2128DAS-B76	Bed Plate		1
77	TS-1505051E	Hex. Socket Cap Screw	M10x35L	4
78	MBS2128DAS-B78	Shaft Locking Block		2
79	MBS2128DAS-B79	Spring Pin	8x20L	2
80	MBS2128DAS-B80G	Bed		1
81	TS-2246082E	Round Head Socket Screw	M6x8L	4
82	MBS2128DAS-B82	Left Cover		1
83	TS-2246082E	Round Head Socket Screw	M6x8L	2
84	MBS2128DAS-B84	Round Head Socket Screw	M4x6L	2
85	MBS2128DAS-B85	Magnifier Holder		1
86	MBS2128DAS-B86	Magnifier		1
87	MBS2128DAS-B87	Wheel Cover		1
88	TS-1505061E	Hex. Socket Cap Screw	M10x40L	1
89	MBS2128DAS-B89	Flat Washer	M10	1
90	MBS2128DAS-B90	Angle Wheel		1
91	MBS2128DAS-B91	Wire Fastener		1
92	TS-1481041E	Steel Hex. Cap Bolt	M5x16L	1
93	MBS2128DAS-B93	Shaft Bush		1
94	MBS2128DAS-B94	Steel Wire		1
95	MBS2128DAS-B95	Angle Spring		1
96	MBS2128DAS-B96	Guide Shaft		1
97	TS-1506041E	Hex. Socket Cap Screw	M12x35L	6
98	TS-1526041E	Set Screw	M12x25L	4
99	TS-1505041E	Hex. Socket Cap Screw	M10x30L	4
100	MBS2128DAS-B100	Spring Washer	M10	4
101	MBS2128DAS-B101	Vise Cylinder		1
102	MBS2128DAS-B102	Oil Less Bush	5540	2
113	TS-2211451E	Steel Hex. Cap Bolt	M12x45L	6
114	MBS2128DAS-B114	Spring Washer	M12	6
115	MBS2128DAS-B115G	Cylinder Bracket		1
116	MBS2128DAS-B116	Spring Pin	8x30L	1
117	MBS2128DAS-B117	Connecting Plate		1
118	MBS2128DAS-B118	Adjusting Screw	M16	4
119	MBS2128DAS-B119	Spring Washer	M8	4
120	TS-1490071E	Steel Hex. Cap Bolt	M8x40L	4

MBS-2128DAS Rotary Mechanism Assembly

Index No.	Part No.	Description	Size	Q'ty
121	TS-1505131E	Hex. Socket Cap Screw	M10x80L	4
122	MBS2128DAS-B122	Linear Bearing Base	SMA40UU	1
134	MBS2128DAS-B134G	Vise Base		1
135	MBS2128DAS-B135	Guide Plate		1
136	TS-1506041E	Hex. Socket Cap Screw	M12x35L	4
137	TS-1490031E	Hex. Cap Bolt	M8x20L	4
138	MBS2128DAS-B138	Spring Washer	M8	4
139	MBS2128DAS-B139G	Table Plate		1
140	MBS2128DAS-B140	Front Vise Slider		1
141	TS-1506031E	Hex. Socket Cap Screw	M12x30L	2
142	MBS2128DAS-B142G	Movable Vise		1
143	TS-1517021E	Flat Head Screw	M12x30L	2
144	MBS2128DAS-B144	Attached Plate		1
145	TS-1504041E	Hex. Socket Cap Screw	M8x20L	4
146	MBS2128DAS-B146	Handle	M12x45L	1
147	MBS2128DAS-B147	Tighten Copper		1
148	TS-1492021E	Steel Hex. Cap Bolt	M12x30L	2
149	MBS2128DAS-B149	Spring Washer	M12	2
150	MBS2128DAS-B150	Flat Washer	M12	2
151	MBS2128DAS-B151G	Vise Locking Block		1
152	MBS2128DAS-B152	Adjusting Screw		2
153	MBS2128DAS-B153	Nut	M12	2
154	MBS2128DAS-B154	Locking Bracket		2
155	MBS2128DAS-B155	Spring Washer	M8	4
156	TS-1505131E	Hex. Socket Cap Screw	M10x80L	4
157	TS-1502031E	Hex. Socket Cap Screw	M5x12L	2
158	MBS2128DAS-B158	Nut	M5	2
159	MBS2128DAS-B159	Vise Locking Plate		1
160	MBS2128DAS-B160	Lining Copper		1
161	TS-1513021E	Flat Head Screw	M5x12L	2

MBS-2128DAS Bow Assembly



MBS-2128DAS Bow Assembly

Index No.	Part No.	Description	Size	Q'ty
1	TS-2248252E	Round Head Socket Screw	M8x25L	4
2	MBS-2128DAS-C2	Safe Locker		1
3	MBS-2128DAS-C3	Spring		1
4	TS-1521051E	Set Screw	M4x12L	2
5	MBS-2128DAS-C5	Bush		1
6	TS-2208201E	Hex. Cap Bolt	M8x20L	2
7	MBS-2128DAS-C7	Spring Washer	M8	2
8	TS-2208201E	Hex. Cap Bolt	M8x20L	1
9	MBS-2128DAS-C9	Holding Bracket		1
10	MBS-2128DAS-C10	Bush		1
11	MBS-2128DAS-C11	Long Bracket		1
12	MBS-2128DAS-C12	Short Bracket		1
13	MBS-2128DAS-C13	Nut	M8	2
14	MBS-2128DAS-C14	Bush		1
15	MBS-2128DAS-C15	Hex. Socket Cap Screw	M12x155L	4
16	MBS-2128DAS-C16	Spring Washer	M12	4
17	MBS-2128DAS-C17	Hex. Socket Cap Screw	M4x30L	2
18	MBS-2128DAS-C18	Limit Switch	EK-1-15-R	1
19	MBS-2128DAS-C19G	Blade Tension Cylinder		1
20	MBS-2128DAS-C20G	Tension Slider		1
21	MBS-2128DAS-C21	Limit Switch	AZD-1001T	1
22	TS-1501081E	Hex. Socket Cap Screw	M4x30L	2
23	MBS-2128DAS-C23	Slide Plate		2
24	MBS-2128DAS-C24	Idle Wheel Washer		1
25	MBS-2128DAS-C25	Spring Washer	M12	1
26	TS-1492021E	Steel Hex. Cap Bolt	M12x30L	1
27	TS-1504051E	Hex. Socket Cap Screw	M8x25L	6
28	MBS-2128DAS-C28	Spring Washer	M8	6
29	MBS-2128DAS-C29	Steel Hex. Cap Bolt	M14x55L	3
30	MBS-2128DAS-C30	Spring Washer	M14	3
31	MBS-2128DAS-C31	Adjusting Screw		3
32	MBS-2128DAS-C32G	Slider Seat		1
33	MBS-2128DAS-C33	Idle Wheel Shaft		1
34	TS-1501081E	Hex. Socket Cap Screw	M4x30L	2
35	MBS-2128DAS-C35	Limit Switch	AZD-1001T	1
36	MBS-2128DAS-C36	Oilless Bush	4040	1
37	TS-1491021E	Hex. Cap Bolt	M10x20L	1
38	MBS-2128DAS-C38	Flat Washer	M10	1
39	MBS-2128DAS-C39	Spring Washer	M10	1
40	MBS-2128DAS-C40	Nut	M10	1
41	MBS-2128DAS-C41	Sensor Bracket		1
42	MBS-2128DAS-C42	VR Sensor		1
43	TS-2244102E	Round Head Socket Screw	M4x10L	2
44	MBS-2128DAS-C44	Sensor Cover		1
45	MBS-2128DAS-C45	Round Head Socket Screw	M5x8L	4
46	MBS-2128DAS-C46	Key	20x12x50L	1
47	MBS-2128DAS-C47	Worm Reducer	135#	1
48	MBS-2128DAS-C48	C Ring	S-20	2
49	MBS-2128DAS-C49	Bracket Shaft		1
50	MBS-2128DAS-C50	Adjusting Screw		1
51	MBS-2128DAS-C51	Key	4x4x10L	1
52	MBS-2128DAS-C52	Adjusting Handle		1
53	MBS-2128DAS-C53	Flat Washer	M6	1
54	TS-1503031E	Hex. Socket Cap Screw	M6x12L	1
55	TS-1491041E	Hex. Cap Bolt	M10x30L	4
56	MBS-2128DAS-C56	Spring Washer	M10	4
57	MBS-2128DAS-C57	Flat Washer	M10	4
58-1	MBS-2128DAS-C58-1	Motor	7.5HP	1
59	MBS-2128DAS-C59	Key	10x8x70L	1
60-1	MBS-2128DAS-C60-1G	Adjusting Bracket		1

MBS-2128DAS Bow Assembly

Index No.	Part No.	Description	Size	Q'ty
61	TS-1504041E	Hex. Socket Cap Screw	M8x20L	4
62	MBS-2128DAS-C62	Spring Washer	M8	4
63	MBS-2128DAS-C63G	Shaft Holder		1
64	MBS-2128DAS-C64	Spring Pin	8x20L	2
65	MBS-2128DAS-C65	Key	12x8x70L	1
65-1	MBS-2128DAS-C65-1	Round Head Socket Screw	M6x8L	4
65-2	MBS-2128DAS-C65-2	Cable Fitting		1
66-1	MBS-2128DAS-C66-1G	Saw Head		1
67	MBS-2128DAS-C67	Round Head Socket Screw	M5x8L	1
68-1	MBS-2128DAS-C68-1	Belt Cover		1
69	MBS-2128DAS-C69	Round Head Socket Screw	M5x8L	3
70-1	MBS-2128DAS-C70-1	Belt	22-700C	2
71	TS-1524011E	Set Screw	M8x8L	1
72	MBS-2128DAS-C72	Motor Pulley		1
73	MBS-2128DAS-C73	Reducer Pulley		1
74	MBS-2128DAS-C74	Locking Washer		1
75	MBS-2128DAS-C75	Spring Washer		1
76	MBS-2128DAS-C76	Steel Hex. Cap Bolt		1
77-1	MBS-2128DAS-C77-1	Cover Plate		1
78	MBS-2128DAS-C78	Round Head Socket Screw	M5x8L	4
79-1	MBS-2128DAS-C79-1	Wheel Cover Plate		1
80	MBS-2128DAS-C80	Round Head Socket Screw	M5x8L	6
81	TS-1503041E	Hex. Socket Cap Screw	M6x16L	3
82	MBS-2128DAS-C82	Wheel Shaft Cover		1
83	MBS-2128DAS-C83	Bearing Nut	AN14	1
84	MBS-2128DAS-C84	Teeth Washer	AW14	1
85	MBS-2128DAS-C85	Idle Wheel		1
86	BB-32014E	Taper Bearing	32014	2
87	TS-1505041E	Hex. Socket Cap Screw	M10x30L	4
88	MBS-2128DAS-C88	Spring Washer	M10	4
89	MBS-2128DAS-C89	Flat Washer	M10	4
90	MBS-2128DAS-C90	Support Plate		2
91	MBS-2128DAS-C91	Press Block		1
92	MBS-2128DAS-C92	Spring Washer	M8	2
93	TS-1504081E	Hex. Socket Cap Screw	M8x40L	2
94	MBS-2128DAS-C94	Guide Roller Shaft		2
95	MBS-2128DAS-C95	Guide Roller		2
	MBS-2128DAS-C95GRA	Guide Roller Assembly (including 94~100)		2
96	BB-6005ZZE	Bearing	6005	4
97	MBS-2128DAS-C97	C Ring	R47	2
98	MBS-2128DAS-C98	Flat Washer	M12	2
99	TS-1506091E	Hex. Socket Cap Screw	M12x60L	2
100	MBS-2128DAS-C100	Spring Washer	M12	2
101	MBS-2128DAS-C101	C Ring	S20	4
102	MBS-2128DAS-C102	Lower Shaft		1
103	MBS-2128DAS-C103	Lower Bracket		1
104	TS-1504041E	Hex. Socket Cap Screw	M8x20L	2
105	MBS-2128DAS-C105	Lift Cylinder		1
106	MBS-2128DAS-C106	Nut	M20xP1.5	1
107	MBS-2128DAS-C107	Eye Bearing	POS20	1
108	MBS-2128DAS-C108	Upper Shaft		1
109	MBS-2128DAS-C109	Saw Head Shaft		1
110	MBS-2128DAS-C110	Shaft Washer		1
111	MBS-2128DAS-C111	Oilless Bush	4040	1
112	MBS-2128DAS-C112	Set Block		2
113	TS-1506111E	Hex. Socket Cap Screw	M12x70L	4
114	MBS-2128DAS-C114	Steel Hex. Cap Bolt	M16x45L	4
115	MBS-2128DAS-C115	Spring Washer	M16	4
116	MBS-2128DAS-C116	Nut	M6	1
117	MBS-2128DAS-C117	Spring Washer	M6	1


MBS-2128DAS Bow Assembly

Index No.	Part No.	Description	Size	Q'ty
118	MBS-2128DAS-C118	Flat Washer	M6	1
119	MBS-2128DAS-C119	Brush		1
120	MBS-2128DAS-C120	Oilless Bush	1212	2
121	MBS-2128DAS-C121	Brush Sleeve		1
122	MBS-2128DAS-C122	Brush Cover		1
123	MBS-2128DAS-C123	Brush Bracket		1
124	TS-2208201E	Hex. Cap Bolt	M8x20L	2
125	MBS-2128DAS-C125	Spring Washer	M8	2
126	MBS-2128DAS-C126	Flat Washer	M8	2
127	MBS-2128DAS-C127	Wing Screw	M6x10L	1
128	MBS-2128DAS-C128	Spring Washer	M6	1
129	TS-1503051E	Hex. Socket Cap Screw	M6x20L	1
130	MBS-2128DAS-C130	Brush Shaft		1
131	MBS-2128DAS-C131	Nut	M20	1
132	MBS-2128DAS-C132	Brush Long Shaft		1
133	MBS-2128DAS-C133	Key	4x15	4
134	MBS-2128DAS-C134	Universal Joint	KT-12	2
135	TS-1522011E	Set Screw	M5x6L	8
136	MBS-2128DAS-C136	Universal Joint Cover		2
137	MBS-2128DAS-C137	Round Head Screw	M5x8L	2
138	MBS-2128DAS-C138	Universal Joint Plate		1
139	MBS-2128DAS-C139	Chip Motor Bracket		1
140	MBS-2128DAS-C140	Spring Washer	M8	2
141	TS-1504041E	Hex. Socket Cap Screw	M8x20L	2
142	MBS-2128DAS-C142	Nut	M6	8
143	MBS-2128DAS-C143	Brush Motor		1
144	MBS-2128DAS-C144	Hex. Socket Cap Screw	M6x90	4
145	MBS-2128DAS-C145	Nut	1/2"	4
146	MBS-2128DAS-C146	Spring Washer	1/2"	4
147	MBS-2128DAS-C147	Upper Bracket		1
148	MBS-2128DAS-C148	Spring Washer	M10	3
149	TS-1505031E	Hex. Socket Cap Screw	M10x25L	3
150	MBS-2128DAS-C150	Spring	9.0x56x54N	2
151	TS-2213351E	Steel Hex. Cap Bolt	M16x35L	1
152	MBS-2128DAS-C152	Spring Washer	M16	1
153	MBS-2128DAS-C153	Driver Wheel Washer		1
154	MBS-2128DAS-C154	Driver Wheel		1
155	MBS-2128DAS-C155	Guide Scale		1
156	TS-1525031E	Set Screw	M10x16L	4
157	TS-1505021E	Hex. Socket Cap Screw	M10x20L	4
158	MBS-2128DAS-C158	Guide Plate		1
159	MBS-2128DAS-C159	Locking Block		2
160	MBS-2128DAS-C160G	Guide Post R		1
161	TS-1524041E	Set Screw	M8x16L	6
162	MBS-2128DAS-C162	Round Head Screw	M5x8L	5
163-1	MBS-2128DAS-C163-1	Blade Guard (Front)		1
164-1	MBS-2128DAS-C164-1	Round Head Socket Screw	M5x8L	2
166	TS-1505051E	Hex. Socket Cap Screw	M10x35L	4
167	MBS-2128DAS-C167	Spring Washer	M10	4
168	MBS-2128DAS-C168	Flat Washer	M10	4
169	MBS-2128DAS-C169G	Guide Post		1
170	MBS-2128DAS-C170	Locking Handle	M12x45L	2
171	MBS-2128DAS-C171	Latch Block		2
172	TS-2248302E	Round Head Screw	M8x30L	4
173	MBS-2128DAS-C173	Pin	φ8x70L	2
174	MBS-2128DAS-C174	Cover Latch		2
175	TS-2246162E	Round Head Screw	M6x16L	4
176-1	MBS-2128DAS-C176-1	Blade Guard (Rear)		1
176-2	MBS-2128DAS-C76-2	Round Head Socket Screw	M5x8L	2
177-1	MBS-2128DAS-C177-1G	Wheel Cover		1

MBS-2128DAS Bow Assembly

Index No.	Part No.	Description	Size	Q'ty
178	MBS-2128DAS-C178	Round Head Screw.....	M8x10L.....	2
179	MBS-2128DAS-C179	Shaft Cover		1
180-1	MBS-2128DAS-C180-1 ...	Handle.....		1
180-2	MBS-2128DAS-C180-2 ...	Big Round Head Screw.....	M6x16L.....	2
180-3	MBS-2128DAS-C180-3 ...	Hex. Cap Bolt	M6x100L.....	2
180-4	MBS-2128DAS-C180-4 ...	Nylon Knob.....		2
180-5	MBS-2128DAS-C180-5 ...	Washer.....	M6	2
180-6	MBS-2128DAS-C180-6 ...	Pipe.....		2
180-7	MBS-2128DAS-C180-7 ...	Nut	M6.....	2
.....	MBS-2128DAS-C181	Blade (not show)2011AC00022 and lower..	41x1.3x6030	1
.....	MBS-2128DAS-C181N....	Blade (not show)21xxAC00023 and higher.	41x1.3x6240	1


MBS-2128DAS Bearing Guide Assembly



MBS-2128DAS Bearing Guide Assembly

Index No.	Part No.	Description	Size	Q'ty
	MBS1824DAS-FBSA	Front Bearing Seat Assembly (included 1~19)		1
1	MBS-2128DAS-D1	Bearing Long Shaft		2
2	BB-6201ZZE	Bearing	6201	4
3	MBS-2128DAS-D3	Bearing Sleeve (Long)		1
4	MBS-2128DAS-D4	Bearing Sleeve (Short)		1
5	MBS-2128DAS-D5	Spring Washer	M10	2
6	MBS-2128DAS-D6	Nut	M10	2
7	TS-1503051E	Hex. Socket Cap Screw	M6x20L	2
8	MBS-2128DAS-D8	Adjusting Screw		1
9	MBS-2128DAS-D9	Adjusting Spring		1
10	MBS-2128DAS-D10	Shaft		1
11	TS-1504081E	Hex. Socket Cap Screw	M8x40L	1
12	MBS-2128DAS-D12	Front Bearing Seat		1
13	BB-6200ZZE	Bearing	6200	2
14	MBS-2128DAS-D14	Bearing Bracket		1
15	MBS-2128DAS-D15	Shaft Sleeve		1
16	MBS-2128DAS-D16	Solid Pin	D10x17	2
17	MBS-2128DAS-D17	Carbide Guide (Fixed) W/Slot		1
18	MBS-2128DAS-D18	Carbide Guide (Adjustable) W/Slot		1
19	MBS-2128DAS-D19	Spring Pin	D5x12L	2
	MBS1824DAS-RBSA	Rear Bearing Seat Assembly (included 20~38)		1
20	MBS-2128DAS-D20	Spring Pin	D5x12L	2
21	MBS-2128DAS-D21	Carbide Guide (Adjustable) W/O Slot		1
22	MBS-2128DAS-D22	Carbide Guide (Fixed) W/O Slot		1
23	MBS-2128DAS-D23	Solid Pin	D10x17	2
24	MBS-2128DAS-D24	Bearing Bracket		1
25	BB-6200ZZE	Bearing	6200	2
26	MBS-2128DAS-D26	Shaft Sleeve		1
27	TS-1503051E	Hex. Socket Cap Screw	M6x20L	2
28	MBS-2128DAS-D28	Rear Bearing Seat		1
29	MBS-2128DAS-D29	Nut	M10	2
30	MBS-2128DAS-D30	Spring Washer	M10	2
31	MBS-2128DAS-D31	Bearing Sleeve (Long)		1
32	TS-1504081E	Hex. Socket Cap Screw	M8x40L	1
33	MBS-2128DAS-D33	Shaft		1
34	MBS-2128DAS-D34	Adjusting Spring		1
35	MBS-2128DAS-D35	Adjusting Screw		1
36	BB-6201ZZE	Bearing	6201	4
37	MBS-2128DAS-D37	Bearing Long Shaft		2
38	MBS-2128DAS-D38	Bearing Sleeve (Short)		1


MBS-2128DAS Coolant System



MBS-2128DAS Coolant System


Index No.	Part No.	Description	Size	Q'ty
1.....	MBS-2128DAS-E1	Cock.....	1/4x1/4	1
2.....	MBS-2128DAS-E2	Spring Washer	M12	1
3.....	MBS-2128DAS-E3	Fixing Bracket.....		1
4.....	MBS-2128DAS-E4	Fitting	1/4x1/4	1
5.....	MBS-2128DAS-E5	Big Round Head Screw.....	M6x8L	2
6.....	MBS-2128DAS-E6	Fitting	1/4x1/4	1
7.....	MBS-2128DAS-E7	Hose.....	1/4"x220mm.....	1
8.....	MBS-2128DAS-E8	Hose.....	1/4"x2400mm.....	1
9.....	MBS-2128DAS-E9	Cock.....	1/4x1/4	1
10.....	MBS-2128DAS-E10.....	Nozzle Set		1
11.....	MBS-2128DAS-E11.....	Nozzle		1
12.....	MBS-2128DAS-E12.....	Y Fit.....		1
13.....	MBS-2128DAS-E13.....	Hose.....	1/4"x3100mm.....	1
14.....	MBS-2128DAS-E14.....	Hose.....	1/4"x1700mm.....	1
15.....	MBS-2128DAS-E15.....	Cock.....	1/4x1/4	1
16.....	MBS-2128DAS-E16.....	90° Fitting	1/4x1/8	1
17.....	MBS-2128DAS-E17.....	Fitting	3/8x1/4	1
18.....	MBS-2128DAS-E18.....	90° Fitting	3/8x1/4	1
19.....	MBS-2128DAS-E19.....	Fitting Set	3/8"	1
20.....	MBS-2128DAS-E20.....	90° Fitting	1/2x3/8	1
21.....	MBS1824DAS-A98.....	Coolant Pump.....	1/6Hpx150L	1
22.....	MBS-2128DAS-E22.....	Hose.....	1/4"x2400mm.....	1


SECTION F




MBS-2128DAS...50000343T 3~400V, 50Hz

Control Circuit Diagram





Panel Board Wiring Diagram



Saw Bow Stroke Wiring Diagram

